


Pro'sKit®

SS-989



2 IN 1 SMD HOT AIR REWORK STATION



User's Manual

1st Edition' 2020

©2020 Copyright by Prokit's Industries Co., Ltd.

Thank you for purchasing Pro'sKit product. The SS-989 2in1 SMD Hot Air Rework Station has been designed to meet high quality standards. Please properly use and care of your product for prolonging service life.

For the complete user manual downloading,

SAFETY INSTRUCTIONS

WARNING

Warnings and cautions are placed at critical points in this manual to direct the operator's attention to significant items. They are defined as follows:

 **WARNING:** Failure to comply with a WARNING may result in serious injury or death.

 **CAUTION:** Failure to comply with a CAUTION may result in injury to the operator, or damage to the items involved. Two examples are given below.

NOTE : A NOTE indicates a procedure or point that is important to the process being describe.

EXAMPLE : AN EXAMPLE is given to demonstrate a particular procedure, point or process.

_ Be sure to comply with following WARNINGS and CAUTIONS for your safety.

WARNING

_ Be sure not to operate the unit with any combination of temperature and air flow settings that makes the thermal protector trip (the heater lamp turns off during use). This could damage the unit.

CAUTION

When the power is ON, the temperature of the hot air and the nozzle ranges from indoor temperature to 480°C (896°F). To avoid injury to personnel or damage to items in the work area, observe the following:


- _ Do not direct the hot air toward personnel or touch the metal parts near the nozzle.**
- _ Do not use the product near combustible gases or flammable materials.**
- _ Advise those in the work area that the unit can reach very high temperatures and should be considered potentially dangerous.**
- _ Turn the power OFF when no longer using the Pro'sKit SS-989 or when leaving it unattended.**
- _ Before replacing parts or storing the unit, allow the unit to cool and then turn the power OFF.**

To prevent accidents and failures, be sure to take the following precautions:

- _ Do not strike the hand piece against hard surfaces or otherwise subject it to physical shock.
- _ Be sure the unit is grounded. Always connect power to a grounded receptacle.
- _ Do not disassemble the pump.
- _ Do not modify the unit.
- _ Use only genuine Pro'sKit replacement parts.
- _ Do not wet the unit or use the unit with wet hands.
- _ Remove power cord by holding the plug – not the wires.
- _ Make sure the work area is well ventilated.
- _ The Pro'sKit SS-989 is not intended for use by children or infirm persons without supervision.
- _ Children should be supervised to ensure that they do not play with the SS-989.

I. Packing list and name of parts

Name of Parts



Packing List

1. 1.SS-989 2 in 1 SMD Hot Air Rework Station
2. User's manual
3. Soldering iron
4. Soldering iron Stand
5. Heat Gun holder
6. Air nozzle x 3
7. Power cord

II. Features and Specifications

Features:

- 2 In 1 rework station to save cost.
- Alumina ceramic soldering iron heating element is more durable and long service lifetime.
- Microprocessor-controlled with Calibration function features accurate temperature control and easy to repair.
- Closed circuit sensor design.
- High power, quick warm up times.
- Individual function start, energy saving.
- LED digital display.
- Quiet operation.
- Auto cool-off process to prolong the life of heating element.
- The cord wire of heat gun is made by silicone which heat-resistant reaches to 200°C.
- Additional ground contact and power cord socket.
- Interchangeable and applicable to most of branded hot air nozzles and tips.

Specifications:

Specification	SS-989E	SS-989B	SS-989H	SS-989C
Power Consumption	700W			
Soldering Power	60W			
Soldering Iron Temperature Range	200°C ~ 480°C (392°F ~ 896°F)			
Hot Air Temperature Range	Indoor temperature ~ 480°C (896°F)			
Soldering Iron Heating Element	Alumina Ceramic			
Hot Air Heating Element	Metal Heating Core			
Pump/Motor Type	Diaphragm Pump			
Air Capacity	24L/min (max)			
Equipment noise	45dB			
Temperature Display	LED			
Power Input	110V-120V~60Hz	220V-240V~50Hz	220V-240V~50Hz	240V~50Hz
Standard Plug				
Dimensions	255(L)x190(W)x140(H)mm			
Weight	4200 g (w/ hot air gun)			
Accessories	Hot Air Gun 9SS-900NE-HG	Hot Air Gun 9SS-900NB-HG	Hot Air Gun 9SS-900NB-HG	Hot Air Gun 9SS-900NC-HG
	Soldering Iron (AC 24V/60W) 9SS-900N-SI x 1pcs, Soldering Stand x 1pcs, Nozzle 9SS-900-A1 (Ø2.2mm) x 1pcs, Nozzle 9SS-900-A2 (Ø6.6mm) x 1pcs, Nozzle 9SS-900-A3 (Ø8.5mm) x 1pcs			

Assembly

A. Station assembly

- Attach the Heat Gun holder

Remove the heat gun holder screw from the side of the station; attach the heat gun holder to the station (Fig. 1)





Fig. 1

B. Attach the nozzle

- Loosen the nozzle mounting screw, attach the nozzle on heat gun then screw
- Show as the figure 2



it.

Fig. 2


C. Electrical Connection and Power ON

- Place the heat gun on the holder.(Fig3)



Fig3

- Loosen the pump securing screw which on the bottom of control station.
- (See below pictures)



CAUTION:
Please remove the pump securing screw (M5x12 with red mark) from the bottom of the station.
Failure to do so may result in serious problems.

注意！
第一次使用前請拆除機身底部緊固氣泵之螺絲（M5x12紅色標記）後，方可通電，否則將可能引起嚴重故障。

- Insert the power plug into socket

- Turn on the power switch and the lamp will be lit
- Don't pull out the power plug instantly after turning off the power switch, because the fan keeps operating to protect heat element. Until the fan stops operation completely, the power plug should not be pulled out.

III. Calibrating the iron and hot air temperature:

The soldering iron and hot air gun should be recalibrated after changing the iron/gun, or replacing the heating element or tip/nozzle.

1. Connect the cord assembly plug to the receptacle on the station.
2. Set the temperature control the knob to 400°C (750°F).
3. Turn the power switch to 'ON' wait until the temperature stabilizes, Remove the CAL pot plug.

When the temperature stabilizes, use a straight-edge(-) screwdriver or small plus(+) screwdriver to adjust the screw (marked CAL at the station) until the tip thermometer indicates a temperature of 400°C(750°F). For hot air temperature calibration, turn the screw clockwise to increase the temperature and counterclockwise to reduce the temperature; for soldering iron temperature calibration is on the contrary. Replace the CAL pot plug.

IV. Operation instructions (SMD rework)

- **Remove SMD components** (such as QFP, SOP, PLCC and so on)

1. Adjust air flow and heat gun temperature to desired level
2. Slip the pick-up puller (optional part) under the component lead. (Fig. 4) If the width of the component does not match the size of the pick-up, adjust the width of the pick-up by squeezing the wire. In case of PLCC or small components such as chip resistors, desolder by using tweezers, etc.
3. Hold the heat gun up on the SMD components, but do not touch the components, and allow the hot air to melt the solder. Be careful not to touch the leads of the components with nozzle.




Fig. 4

4. When the soldering tin is melted, remove the SMD components by lifting the pick up puller (Fig. 5)




Fig. 5

5. After removing SMD components, remove residual soldering solder tin with desoldering tool.

●SMD rework operation instructions

1. Apply proper quantity of solder paste and install the SMD components on PCB.
2. Refer to (Fig. 6) to preheating components



Fig. 6

3. Heat the lead frame evenly (Fig. 7)




Fig. 7

4. Cleaning

When soldering is completed, clean the residual flux from the board with an appropriate cleaner.

V. Soldering iron operation instructions

1. Soldering iron stand assembly

- Install the cleaning sponge into the seat. (Fig. 8)



Fig. 8

*****ATTENTION*****

Sponge will swell when wet. Dampen the sponge with water and squeeze dry before using. The tips may be damaged when used with dry sponge.

2. Insert soldering iron into the stand.
3. Take out the protection tube on the top of soldering iron.
4. Connect soldering iron cable to the 5 hole socket on control station

*****ATTENTION*****

Switch off the power before inserting or pulling out the plug

5. Insert power plug into power socket then turn on power switch.
6. Adjust temperature with regulation temperature knob.

*****ATTENTION*****

High temperature shortens tip life and may cause thermal shock to components. Always use the lowest possible temperature when soldering. It will also provide better protection for some components which sensitive to temperature.

*****ATTENTION*****

Always put soldering iron into holder after use.

*****ATTENTION*****

Always clean the soldering iron tip after use and coat it with fresh solder to prevent oxidation and prolong tip life.

7. Soldering iron tip maintenance and operation

- Always clean the soldering tip before use to remove any residual solder or flux adhering to it. Use a clean and moist cleaning sponge. Contaminants on the tip have many detrimental effects including reduced heat conductivity which contribute to poor soldering performance.
- If the soldering iron is not in use, do not keep it at high temperature for long time otherwise the tin flux will become oxidized and reduce heat conductivity function.
- After use, always clean the soldering iron tip after use and coat it with fresh solder to prevent oxidation and prolong tip life.
- Checking and cleaning the soldering iron tip

ATTENTION

- ◆ Never cut the oxide on soldering iron tip by cutter.
- ◆ Set the temperature at 250°C or 482.°F.
- ◆ After the temperature is stable, clean soldering iron tip with sponge, and check its condition. If the tip is badly worn or deformed, replace it.
- ◆ If the tin-plating part of soldering iron tip covered with black oxide, apply fresh solder containing flux and clean the tip again. Repeat until all the oxide is removed then coat the tip with fresh solder.
- ◆ If the soldering iron tip gets deformed, replace it with a new one.

VI. Fuse replacement

When fuse is blown, replace with the same type of fuse. (refer to below picture)

1. Unplug the power cord from the power receptacle.
2. The fuse holder is located under the AC power receptacle, use the slotted (–) screwdriver to loosen the fuse holder.
3. Replace the fuse with new one.
4. Put the fuse holder back in place.



VII. Trouble shooting



Warning:

Before checking the inside of the SS-989 or replacing parts, be sure to disconnect the power plug. Failure to do so may result in electric shock.

Defect Situation	Possible Problem	Solution
Dead, Doesn't work	Blown fuse	Change new fuse SS-989E(110V) 250V 8A SS-989B(220V) 250V 5A SS-989H(220V) 250V 5A SS-989C(240V) 250V 5A
	PCB Board broken	Contact vendor for repair
Soldering Iron doesn't heat up	Panel display S-E, plug didn't connect properly	Reconnect the plug of Soldering Iron
	Heating Element broken	Replacing heating element
Heat Gun air Temperature doesn't heat up	Heating Element broken	Replacing heating element
Heat Gun airflow level abnormal	Internal pipe obstruction or loosen caused air leakage	Clearing the internal pipe, reconnect the pipe tightly.
	Pump securing screws haven't loosened	Loosen the pump securing screw which on the bottom of control station.
Display shows abnormal	Transportation caused inside PCB board didn't connect properly	Open the case, reconnect the PCB board
	Input voltage lower than standard request	Check with local power service provider
Temperature unit display abnormal	IC broken	Contact vendor for repair